

D005SNG



Smove

Packing

Boxes 250 pcs.
Cartons 2.000 pcs.

D005SNB



Smove

Packing

Boxes 250 pcs.
Cartons 2.000 pcs.

Technical information about the installation of SMOVE D005SN to be recessed

Insert Smove D005 into the cabinet side opposite the hinges. For an optimal performance, we suggest that Smove D005 is positioned at the centre of the side panel.

It is suggested for doors from 450 mm to 600 mm width.

For wood-based and alu-framed doors over 1600 mm height, it may be necessary to use two Smove, one to be inserted into the upper part and the second into the lower part of the cabinet side opposite the hinges.



To be recessed - Assembly instructions

Drill a hole \varnothing 10 mm and min. 50 mm depth in the cabinet.
Insert Smove into the hole.

