

D006SNG



Smove

Packing

Boxes 250 pcs.
Cartons 2.000 pcs.

D006SNB



Smove

Packing

Boxes 250 pcs.
Cartons 2.000 pcs.

Technical information about the installation of SMOVE D006SN to be recessed

Insert Smove D006 at the centre of the top or the base panel of the cabinet.

For wood-based and alu-framed doors over 1600 mm height, it may be necessary to use two Smove, one to be inserted into the top and the second into the base panel of the cabinet.



To be recessed - Assembly instructions

Drill a hole \varnothing 10 mm and min. 50 mm depth in the cabinet.
Insert Smove into the hole.

