

D009SNG



Smove

Packing

Boxes 250 pcs.
Cartons 2.000 pcs.

D009SNB



Smove

Packing

Boxes 250 pcs.
Cartons 2.000 pcs.

Technical information about the installation of SMOVE D009SN to be recessed

Insert Smove D009 into the base panel of the cabinet on the hinged side.

Smove D009 is used for doors between 720 mm and 1600 mm high.

Drilling distance from the cabinet side:

- for hinges with **arm 0** mm the drilling distance equals **15 mm** plus the base height;
- for hinges with **arm 5** mm the drilling distance equals **20 mm** plus the base height;
- for hinges with **arm 9** mm the drilling distance equals **24 mm** plus the base height.



To be recessed - Assembly instructions

Drill a hole \varnothing 10 mm and min. 50 mm depth in the cabinet.
Insert Smove into the hole.

