



Luxer Room
technical information

Luxer Room

Standard track




Electric track for shelves with LED light




Luxer Room

Standard track - Corner mounting

Alternate the insertion of the spacer and the supports for the wall fixing




Electrified track for shelves with LED light - Corner mounting





Luxer Room

Assembly instructions

If present, secure and straighten the corner profile.
Then proceed with the other uprights, always checking that they are parallel to each other.
We suggest that the parallelism between the slots is checked by inserting 2 brackets
For the perfect alignment of the upright profiles see the chapter "Adjustments"




Panel dimensions and fixing clips




Luxer Room

Calculation of panel dimensions for corner mounting and end caps




Adjustments



Height adjustment of the foot




Sideways adjustment of the single upright profile ± 4.5 mm





Depth adjustment of the single upright profile



Sideways adjustment of the angular upright profile



Depth adjustment of the angular upright profile



Front adjustment of one upright profile involves lateral displacement of the other.

