



Fixing full-extension runner on cabinet side.




The oval slot allows the easy alignment of drawer frontals particularly in multi drawer and Push applications.


Drilling positions for runner on cabinet side.
Full-extension



For the function Push is required an A value = 2,5 mm.
This value is obtained by placing the runner at 37 mm from the edge of the cabinet.



Detail of the rear additional fixing hole



Drawer setting

Drawer setting: abbreviations


Chest of drawers

SP = Thickness of the drawer

LN = Nominal runner length

PM = Depth of the cabinet


X = Internal width of the cabinet



Drawer dimensions

LC = Runner length - 10 mm

X - 41 = Internal width of the drawer




The drawer length is 10 mm shorter than the runner length

The internal width of the drawer is 41 mm less than the internal width of the cabinet


Drawer drilling

Drawer with frontal - three-sided (view from below)
 Template for drawer drilling - see page 186



Drawer drilling




Internal drawer - four-sided (view from below)
 Template for drawer drilling - see page 26



Rear hook

drawer locating pin

security pin





Fixing of the drawer security pin

Available on all runner versions



This operation is tool free

The device locks the drawer onto the runners






Height adjustment + 3 mm

Initial position of the lever for the height adjustment.






Turn the lever towards the front of the drawer to achieve the height adjustment.
This operation is tool free.



Pin-fix clip - adjustments

Depth adjustment + 2 mm - 2 mm

Rotate the black wheel towards the front of the drawer to increase the gap between the front and the side.
This operation is tool free.



Rotate the black wheel towards the back of the drawer to reduce the gap between the front and the side.
This operation is tool free.

