


The Series 200 make up an integrated system of hinges developed to provide a solution to any situation involving concealed hinges.


Bright nickel plated steel cup and arm.

Dimensions of the Ø 35 mm cup.



Constant "L" value of 0.7 mm (it does not change during side adjustment).

Approx. number of hinges required according to the door dimension and weight.



Adjustments

Compensating side adjustment from -1.5 mm to +4.5 mm.

Height adjustment ± 2 mm.

Depth adjustment with Series 200 mounting plates +2.8 mm.

Depth adjustment with Domi snap-on mounting plates from -0.5 mm to +2.8 mm.

Anti-sliding safety stop.





Mounting plates







Symmetrical and asymmetrical bright nickel plated steel or die-cast Series 200 mounting plates.

Snap-on assembly on Domi mounting plates.

Positioning with pre-determined stop on traditional Series 200 mounting plates.

N.B. : Use POZIDRIVE No. 2 screwdrivers for all screws.

													
Wood screw		A	A	A	A	P	P	P	P	U	U	U	U

													
		94° 110° 120° 155° 165°	94° 110° 120° 155° 165°	94° 110° 120° 155° 165°									
Rapido		6	6	6	6	7	7	7	7	2	2	2	2
Dowel		B	B	B	B	R	R	R	R	W	W	W	W
Logica		I	I	I	I	J	J	J	J	Q	Q	Q	Q

Use this table to identify the available drillings and fixings.

Fill the third position of the hinge code number with the letter or the number corresponding to your choice. I.e.: C2_BA99.

↑
Fill this position with the chosen letter or number.



Technical information

Hinges for wooden doors with positive angled assembly.

11 mm deep metal cup.

94° opening.

Possible drilling distance on the door (K): from 3 to 9 mm.

Compatible with all traditional Series 200 mounting plates and with all Domi snap-on mounting plates.

Packing


Boxes 150 pcs.

Pallets 3.600 pcs.


CA sprung hinge

The solution of assembly problems where doors are mounted at a positive or negative angle requires the verification of drilling distances by a practical trial. Please do not hesitate to consult our technical support department for assistance.

Use the tables "Drillings and fixings" at page 3 to complete the code number of the desired hinge.




Arm **15°**




CA - C2_BZ99

Arm **24°**




CA - C2_BU99

Arm **30°**




CA - C2_BE99

Arm 30°




CA - C2_BT99

Arm 37°




CA - C2_BK99

Arm 45°




CA - C2_BM99

Arm 45°



CA - C2_BV99

Arm 45°



CA - C2_BM99AC